



NEW VINTAGE USA
2415 BURDETTE
FERNDALE, MI 48220
248.2594964 PHONE
248.656.8291 FAX
info@newvintageusa.com
www.newvintageusa.com

88052-09 51-52 CHEVY CAR 2 GA MOUNT

CONTENTS:

- 2 EA 3D PRINTED ABS ANTI-RATTLE EYEBROW ADAPTERS
- 2 EA BRACKETS
- 2 EA BRACKET SPACERS (OPTIONAL)

Adapter rings installed, original
eyebrows install over this



Adapter bracket with back clamp
installed



Final installation

INSTALLATION:

Remove original instruments.
Remove original eyebrows. The parts are easily removable and held in place with a few sections bent over the lens. Carefully pry straight and remove.

Place adapter on NVU gauge lens as shown. This part is held in place with compression but you can adhere to the bezel if you like with adhesive tape or silicone for easier installation

The adapters are black but can be painted if desired. They are not very visible once installed, the black will look like a shadow.

Place original gauge eyebrows in position on the adapters. No not adhere at this time. Make sure they are straight once installed if any adhesive is to be used. Adhesive is not required, the parts are held in with compression

Install adapter bracket to gauge, and bolt to original mounting points, install back clamp

Align eyebrows and tighten as needed.

There are 2 spacers included in each kit, you may or may not need them depending on the build variation in your vehicle. These can be installed between the bracket and gauge to move the instruments closer to the dash.